


INCLUDED PARTS







Р3

1x

P2











*Bolt shown actual size

10x




Please read before beginning assembly and be sure to wear eye protection to avoid injury, particularly if using power tools

surface like a blanket, carpet, or the flattened cardboard box the furniture was shipped in. When removing the furniture from the carton and if using the carton for an assembly surface, please CAREFULLY remove all staples that held the shipping carton together. protective film on one side. This surface is hidden after assembly so the film can remain together you likely have something wrong and you should reread the instructions to ensure you are aligning the proper components. The various "Blocks" used in assembly may have a loosening of the clutch to install bolts in inserts as you can easily overtighten and damage the product. low/ medium torque. We do not recommend using an electric drill with a cord or without a screw gun or drill if you have one and know how to use it properly. Set the clutch setting at on the Block or it can be removed. Although not recommended, Components should not be unnecessarily forced together! If it seems parts aren't fitting To avoid damaging the furniture, perform the assembly of your new furniture on a clean, soft **Please recycle the cardboard box and all paper and plastic packaging materials. These can scratch you and the furniture and we don't want that to happen to either of you. nstall bolts in insure come standard with a threau-roce of the bolts over time. Start all bolts by hand of the bolts over time of the bolts over time. Start all bolts by hand of the bolts over time. thread-locking compound by hand and then use the Allen Key/ tightly you may use a cordless pre-applied reduce

BLOCK & BOLT INSTALLATION


Insert bolts through **countersunk** hole side of blocks as shown below. When done properly, the top of the bolt will sit even or flush with the top surface of the block.





Included in the carton for use in tightening all bolts..

PRODUCT CARE




furniture and satisfied with your purchase and we back that up with a comprehensive Warranty TimberTech is known for making beautiful, high-quality, outdoor living products that last and our Invite Collection of Outdoor Furniture is no exception. We want you to be happy that you chose our WARRANTY Your new furniture is a very low maintenance product. You'll never need to paint or stain it and it can be left outside all year regardless of the season. However, we are pretty sure your furniture will get a lot of use and will at some point need cleaning. We recommend using clean water from a faucet or or two of your favorite eco-friendly soap to the wash will get everything squeaky clean. garden hose and incorporating a soft bristle brush to remove light dirt or spills. Adding a tablespoon Removing mineral deposits from hard water or other tougher cleaning jobs can be done with TimberTech Deck Cleaner which is specially formulated for this type of cleaning.

the problem. If there is any damage, please save all of your packaging material in case a return is has not been damaged during shipping. If damage has occurred, please take digital pictures of the damaged furniture and the box it was shipped in, and call Customer Service using our toll free Sometimes accidents happen. Please inspect your furniture when you receive it to make sure that it Please see the TimberTech + Loll Invite Collection Warranty for complete details. number: 877.275.2935. The damage will be assessed and you will be contacted with a solution to PRODUCT DAMAGED IN SHIPMENT

Reach out if you need We want you to love your new furniture.

.877.275.2935

Chicago, IL 60607 1330 W Fulton Market, Suite #350







ASSEMBLY IN STRUCTIONS & PRODUCT INFO:

